Ozone Vacu-vials® Kit

K-7423: 0 - 5.00 ppm (Prog. # 133)


Instrument Set-up

For CHEMetrics photometers, follow the **Setup and Measurement Procedures** in the operator's manual. For spectrophotometers, follow the manufacturer's instructions to set the wavelength to 515 nm and to zero the instrument using the ZERO ampoule supplied.

Test Procedure


- 1. Add 5 drops of S-2500 Activator Solution to the empty sample cup (fig. 1).
- 2. Fill the sample cup to the 25 mL mark with the sample to be tested, being careful to minimize turbulence (fig. 2).


Note: Ozone loss from sample occurs rapidly. Do not transfer sample to other containers.



- 4. To mix the ampoule, invert it several times, allowing the bubble to travel from end to end. Tap the bottom of the ampoule on a hard surface to cause any tiny bubbles that have collected on the ampoule wall to rise to the top of the liquid in the ampoule.
- 5. Dry the ampoule. Obtain a test result **1 minute** after snapping tip.







 Insert the Vacu-vial ampoule into the photometer, flat end first, and obtain a reading in ppm (mg/Liter) ozone (O₃).

NOTE: If using a spectrophotometer that is not pre-calibrated for CHEMetrics products, then use the equation below or the Concentration Calculator on the website.

$$ppm = 1.10 (abs)^2 + 2.16 (abs)$$

Test Method

The Ozone Vacu-vials[®]1 test kit employs the DPD chemistry.^{2,3} The sample is treated with an excess of potassium iodide. Ozone oxidizes the iodide to iodine. The iodine then oxidizes DPD (N,N-diethyl-p-phenylenediamine) to form a pink colored species in direct proportion to the ozone concentration.

Various oxidizing agents such as halogens, ferric ions and cupric ions will produce high test results.

- Vacu-vials is a registered trademark of AquaPhoenix Scientific, LLC U.S. Patent No. 3,634,038
- 2. APHA Standard Methods, 23rd ed., Method 4500-Cl G 2000
- 3. EPA Methods for Chemical Analysis of Water and Wastes, method 330.5 (1983)

Safety Information

Read SDS before performing this test procedure. Wear safety glasses and protective gloves.

