

# Sulfite Titrets® Kit

**K-9602:** 2 - 20 ppm  
**K-9605:** 5 - 50 ppm  
**K-9610:** 10 - 100 ppm  
**K-9650:** 50 - 500 ppm

## Test Procedure

1. Fill the sample cup to the 20 mL mark with the sample to be tested (fig. 1).
2. Add 5 drops of S-9600 Neutralizer Solution (fig. 2). Stir to mix the contents of the cup. Wait **30 seconds**.




Figure 1




Figure 2

3. Slide the open end of the valve assembly over the tapered tip of the Titret so that it fits snugly to the white reference line (fig. 3).
4. Snap the tip of the ampoule at the black snap ring (fig. 4).




Figure 3

5. Lift the control bar and insert the Titret assembly into the Titrettor (fig. 5).

**NOTE:** The rigid sample pipe will extend approximately 1.5 inches beyond the body of the Titrettor.

6. Hold the Titrettor with the sample pipe in the sample. Press the control bar firmly, but briefly, to pull in a small amount of sample (fig. 6). The contents will turn **BLUE to VERY DARK BLUE** (black). Wait 30 seconds.

**NOTE:** NEVER press the control bar unless the sample pipe is in the sample.

7. Press the control bar again to draw another small amount of sample into the ampoule (fig. 6).




Figure 5

8. Rock the entire assembly to mix the contents of the ampoule. Watch for a colorchange from **BLUE to COLORLESS** (may be cloudy).
9. Repeat steps 7 and 8 until a permanent color change occurs.
10. When the color of the liquid in the ampoule changes to **COLORLESS** (maybe cloudy), remove the ampoule from the Titrettor. Hold the ampoule, tip pointed upward, and read the scale opposite the liquid level (fig. 7). Results are expressed in ppm (m/Liter) sulfite ( $\text{SO}_3$ ).

**K-9650 only:** Multiply scale unit by 50.




Figure 6




Figure 7

## Interpretation of Test Results

If the contents of the ampoule do not turn blue in Step # 6, the sulfite concentration in the sample is above the test range. If the ampoule fills completely and the contents do not turn colorless (may be cloudy), the sulfite concentration is below the test range.

## Test Method

The Sulfite Titrets®<sup>1</sup> test kits employ the Iodometric chemistry. In an acidic solution, sulfite is titrated with an iodide-iodate titrant and a starch indicator<sup>2,3,4</sup>. Sulfamic acid is added to the sample to prevent interference from nitrite.

1. Titrets is a registered trademark of AquaPhoenix Scientific, LLC U.S. Patent No. 4,332,769

2. ASTM D 1339-84, Sulfite Ion in Water, Test Method C

3. APHA Standard Methods, 23rd ed., Method 4500-SO32- B - 2000

4. EPA Methods for Chemical Analysis of Water and Wastes, method 377.1 (1983)

## Safety Information

Read SDS before performing this test procedure. Wear safety glasses and protective gloves.